

Date: Thursday, 07/02/2008 11:11:40 AM  
 User: Linda Lacelle

## Process Sheet

SPLIT

Customer : CU-DAR001 Dart Helicopters Services  
 Job Number : 37292  
 Estimate Number : 12712  
 P.O. Number :  
 This Issue : 07/02/2008 S.O. No. :  
 Prsht Rev. : NC  
 First Issue : / / Type : SMALL / MED FAB  
 Previous Run : 36714  
 Drawing Name : WEARPAD  
 Part Number : D35371  
 Drawing Number : D3537 REV C  
 Project Number : N/A  
 Drawing Revision : C  
 Material :  
 Due Date : 28/02/2008 Qty: 100 Um: Each  
 Written By :  
 Checked & Approved By :  
 Comment : Est Rev. A New Issue 07-02-14 JLM

## Additional Product

Job Number:



Seq. #: Machine Or Operation: Description :

1.0 M304S16GA 304/316 .063 Sheet



Comment: Qty.: 0.1113 sf(s)/Unit Total: 11.1300 sf(s)

M304S16GA .063" 304 SS SHEET

Batch: 106860 RB 8-2-12

2.0 WATER JET FLOW WATER JET



Comment: FLOW WATER JET

1-Cut as per Dwg D3537

Dwg Rev: C

Prog Rev: C

RB 8-2-12

129

2-Deburr if necessary

RB 8-2-12

3.0 QC2 INSPECT PARTS AS THEY COME OFF MACHINE



Comment: INSPECT PARTS AS THEY COME OFF MACHINE

4.0 QC8 SECOND CHECK



Comment: SECOND CHECK

05/02/12 counts 125

5.0 BRAKE NC NC BRAKE



Comment: NC BRAKE

1-Form as per Dwg D3537 on CNC brake using Jigs DT 8261 and DT 8326.

2-Identify as D3537-1

05/02/19 129 SB





Date: Thursday, 07/02/2008 11:11:40 AM  
User: Linda Lacelle

## Process Sheet

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: WEARPAD

Job Number: 37292

Part Number: D35371

Job Number:



Seq. #:

Machine Or Operation:

Description:

6.0

LARGE FAB 1

LARGE FABRICATION RESOURCE 1



Comment: LARGE FABRICATION RESOURCE 1

Qty Description Batch  
A/R 2059B Hardcoat m106834  
1-Weld as per Dwg D3537 using Jig DT 8210 m107051  
2-Remove any weld that penetrated through Wearpad if necessary

08/04/07  
Took 10 for  
testing

7.0

QC10

VISUAL WELDING INSPECTION



Comment: VISUAL WELDING INSPECTION

8.0

QC5

INSPECT WORK TO CURRENT STEP



Comment: INSPECT WORK TO CURRENT STEP

9.0

POWDER COATING

POWDER COATING



Comment: POWDER COATING

Powder Coat Grey Sandtex (Ref: 4.3.5.6) as per QSI 005 4.3

10.0

QC3

INSPECT POWDER COAT/CHEMICAL CONVERSION



Comment: INSPECT POWDER COAT/CHEMICAL CONVERSION

11.0

PACKAGING 1

PACKAGING RESOURCE #1



Comment: PACKAGING RESOURCE #1

Identify and Stock  
Location: F-P 20

12.0

QC21

FINAL INSPECTION/W/O RELEASE




Comment: FINAL INSPECTION/W/O RELEASE

Job Completion







### D3537-1F FLAT PATTERN




### D3537-3F FLAT PATTERN




### D3537-1 LONGITUDINAL BEND (MADE FROM D3537-1F)




### D3537-3 LONGITUDINAL BEND (MADE FROM D3537-3F)



### D3537-5 LONGITUDINAL BEND (MADE FROM D3537-1F)




### SECTION A-A



APPLY 2 LAYERS OF  
2059B HARDCOAT WELDS  
TO WITHIN 0.25 OF  
WEARPAD ENDS  
0.188 TO 0.250 THICK


### SECTION B-B



D2941-300  
REMOVE POWDER  
COAT FROM THESE  
SURFACES

**RELEASED**  
07.05.03 AE  
PER EUN 962

### D3537-7 LONGITUDINAL BEND (MADE FROM D3537-3F)



### D3537-1/-3/-5/-7 WEARPAD NOTES

- 1) MATERIAL: AISI 304/316 SS SHEET PER AMS 5513 OR AMS 5524, 16 GAUGE (0.063 THICK)  
(REF DART SPEC. M304S16GA)
- 2) BREAK ALL SHARP CORNERS 0.063 MAX
- 3) WELD PER QSI 004
- 4) FINISH: POWDER COAT GREY SANDTEX (4.3.5.6) PER QSI 005 4.3
- 5) TOLERANCES ARE PER DART QSI 018 UNLESS OTHERWISE NOTED
- 6) ALL DIMENSIONS ARE IN INCHES


COPYRIGHT © 2008 BY DART AEROSPACE USA, INC.

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL  
AND IS SUPPLIED ON THE EXPRESS CONDITION  
THAT IT IS NOT TO BE USED FOR ANY PURPOSE  
OR COPIED OR COMMUNICATED TO ANY OTHER  
PERSON WITHOUT WRITTEN PERMISSION FROM  
DART AEROSPACE USA, INC.

C	07.04.13	WIDEN JAE TO 0.380, WELD PATTERN
B	07.03.20	ADD AMS 5513 AND AMS 5524
A	06.11.06	NEW ISSUE
DESIGN	C.B.	DRAWN BY PH
CHECKED	4	APPROVED 4
DATE	07.04.13	TITLE WEARPAD
DRAWING NO. D3537		REV. C
		SHEET 1 OF 1
		SCALE 1:2

**DART** DART AEROSPACE USA, INC.  
PORT HADLOCK, MA






















W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: D3537-1 PAR #: N/A Fault Category: Prod / App. Large NCR: Yes No DQA: AD Date: 08/04/14  
 QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR: <u>37292</u>		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			
08/04/14	#60	four parts scrap. 3 parts were ground too much. I had it ground in under a main a large step		Scrap and Destroy all four (containing) parts. no replace	SP 08-04-14			
		2 have the end of the plate ground down to under 0.050". the fourth part was. Re-welded in a area where there was a burn out in metal		inform welder that it is not acceptable to repair a mistake with out informing QC or Eng.				
		RC employee thought it was ok to fix mistakes and was it a problem.						

NOTE: Date & initial all entries

